

ASSEMBLY INSTRUCTIONS MILFORD COOP

1. Lay floor panel down with bearers to ground
2. Take one side panel with sloping top and the front panel with pop hole entrance, fit corners tightly together ensuring that top of frames are at same level. The frame of these panels should sit on the edge of the floor with the cladding passing down the sides. Screw together with screws already located in side panel.
3. Repeat with other side panel and remaining rear panel of the house. Screw all 4 sides of house together before fixing panels to floor. This ensures correct positioning
4. Fixing Roof.
Locate roof assembly onto house with free end of hinges positioned to the front of the frame directly above the mesh vent in house front panel. Centralise and secure with screws provided.
5. Fit Roosting bars #2 into sockets provided.
Fit nest box insert (a piece of plywood with corners angled along one long side) into slots provided at end of house opposite to pop hole

LITTLEACRE PRODUCTS
Tel. 01827 215697