

## **ASSEMBLY INSTRUCTIONS OXFORD DUCK HOUSE**

1. Lay floor panel down with bearers to the ground.
2. Take the tall panel with mesh vent at the top and one side panel with sloping top, fit corners tightly together ensuring that top of frames are at same level. The bottom frame of these panels should sit on the edge of the floor with the cladding passing down the sides. Screw together with screws already located in panel.
3. Repeat with other side panel with sloping top.
4. Take the narrow panel fitted with wire mesh and position it at the top of the remaining open side (The rear of the house). Ensure that the top of the frames are at the same level and fix with the screws located in panel. Now take the lift- out rear panel, fitted with handles and fit it into position engaging the top first then closing it at the bottom and secure with turn buttons fitted each side. Check that the corner joints at the rear fit tightly together then secure all panels to the floor.
5. Fixing Roof.  
Locate roof assembly onto house with free end of hinges positioned to the front of the frame directly above the mesh vent in house front panel. Centralise and secure with screws provided.

***LITTLEACRE PRODUCTS***

***Tel. 01827 215697***