

ASSEMBLY INSTRUCTIONS

Weeford, Swinford, Stafford

1. Take front panel of house with pop hole entrance and one side panel, fit corners tightly together ensuring that top of frames are at same level. Screw together with screws already located in side panel.
2. Repeat with other side panel and rear panel of house.
3. Locate nest box in side panel aperture ensuring that the base of the nest box sits tightly on top of the board at bottom of aperture, screw to side frames in this position with screws provided in nest box.
5. Slide nest box lid into gap between top of nest box and underside of hinge bar (ensuring that the nest box lid is positioned with stiffening batten facing down into the nest box and toward the house)
6. Centralise lid, locate free end of double knuckle hinges onto top of lid where they naturally sit and secure by screwing through the lid above stiffening batten with screws provided separately.
7. Slide floor tray, with raised edges uppermost, into position through aperture at rear of house.
Stafford Major only. Locate floor tray centre support in position provided, slide trays in to place and fix support to allow free movement of trays.
8. Fixing Roof.
Locate roof assembly onto house with free end of hinges positioned to the front of the frame directly above the mesh vent in house front panel. Centralise and secure with screws provided.
9. **Stafford only.** Locate ramp on ledge below pop hole allowing protruding screws to spike into position. This allows easy removal when moving the unit.
10. Locate perch(s) in sockets provided .

LITTLEACRE PRODUCTS
Tel. 01827 215687