

ASSEMBLY INSTRUCTIONS UNIVERSAL PET RUN

1. Lay floor panel down with bearers to ground
2. Take one long side panel with run side attached and a house panel with pop hole entrance, fit corners tightly together ensuring that top of frames are at same level. The frame of these panels should sit on the edge of the floor with the cladding passing down the sides. Screw together with screws already located in side panel.
3. Repeat with other long side panel and remaining panel of house. Screw all 4 sides of house together before fixing panels to floor. This ensures correct positioning
4. Fit run end panel.
The screws already fitted to side panels fix into the vertical bars of the end panel. Ensure frame tops are level.
5. Fixing Roof.
Locate roof assembly onto house with free end of hinges positioned to the front of the frame directly above the mesh vent in house front panel. Centralise and secure with screws provided.
6. Fit run top using locating lugs to run sides. The top will slide away from the house to access the pop hole then sliding it further will allow complete removal.

LITTLEACRE PRODUCTS
Tel. 01827 215697