ASSEMBLY INSTRUCTIONS Lynford, Aylesford Plus Models

- 1. Take one long side panel and house front panel with pop hole entrance, fit corners tightly together ensuring that top of frames are at same level. Screw together with screws already located in side panel.
- 2. Repeat with other long side panel and rear panel of house. Fit run end panel. The screws already fitted to side panel fix into the vertical bars of the end panel. Ensure frame tops are level.
- 3 Take axle tube and slide through brackets fitted to underside of house Centralise tube then place one washer followed by one wheel then second washer and secure with split cotter pin into holes at end of tube. Repeat procedure for other side.
- 4. Locate nest box in side panel aperture ensuring that the base of the nest box sits tightly on <u>top</u> of the board at bottom of aperture, screw to side frames in this position with screws provided in nest box.
- 5. Slide nest box lid into gap between top of nest box and underside of hinge bar (ensuring that the nest box lid is positioned with stiffening batten facing down into the nest box and toward the house)
- 6. Centralise lid, locate free end of double knuckle hinges onto lid where they naturally sit and secure by screwing through the lid above stiffening batten with screws provided separately.
- 7. Slide floor tray into position through aperture at rear of house.
- 8. Fixing Roof.

Locate roof assembly onto house with free end of hinges positioned to the front of the frame directly above the mesh vent in house front panel. Centralise and secure with screws provided.

- 9. Fit run top using locating lugs to run sides. The 'L' shaped lugs go to the end of the run and will slide under the handles and secure the run top when fully closed. The top will slide away from the house to access the pop hole then sliding it further will allow complete removal.
- 10. Locate perch(s) in sockets provided.

LITTLEACRE PRODUCTS Tel. 01827 215697